

LED Cinema Display (24-inch)

Apple Recycler Guide

July 2023

Contents

- 3 About This Guide
- 4 Identification
- 5 Directive 2012/19/EU Annex VII Components
- 6 Safety Considerations
- 7 Recommended Tools
- 8 Disassembly Instructions
- 30 Material Categorization of Output Fractions

About This Guide

Apple Recycler Guides provide guidance for electronics recyclers on how to disassemble products to maximize recovery of resources. The guides provide step-by-step disassembly instructions and information on the material composition to help recyclers direct fractions to the appropriate material recycler.

To conserve important resources, we work to reduce the materials we use and aim to one day source only recycled or renewable materials in our products. A key path to reaching that goal is resource recovery from end-of-life electronics.

Disassembly procedures are intended to be performed only by trained electronics recycling professionals. The recycler is responsible for independently evaluating and ensuring compliance with all applicable environmental, health, and safety laws related to the work. These include but are not limited to laws relating to the management, handling, shipping, and disposal of the outputs of this work as waste and laws in place to ensure the health and safety of all employees who support this work.

For questions or feedback about this guide, email contactesci@apple.com.

Identification

You can find the model number of the display on the bottom of the display stand. To view the model number, hold the sides of the display and gently lay the display facedown on a soft, clean towel or cloth.



Model number: A1267

Directive 2012/19/EU Annex VII Components

Directive 2012/19/EU Annex VII requirements apply to the following substances and components.

Substance/Component	Apple Part Name	Removal Instructions
Printed circuit board if the surface is greater than 10 square centimeters	Main logic board, display logic board, light-emitting diode (LED) logic boards, power supply logic board	Follow steps 1–15
Cover glass and liquid crystal display (LCD) cell if the surface is greater than 100 square centimeters	LCD cell	Follow steps 1–8
External electrical cables	Built-in Mini DisplayPort, MagSafe cable, USB 2.0 cord	Follow step 1
No further substances or components as listed in Annex VII		

Safety Considerations

The recycler is responsible for independently evaluating all activities undertaken by its employees to perform or support the work and ensuring compliance with all applicable health and safety laws related to the work. These include but are not limited to laws relating to the health and safety of all employees who perform or support this work. The recycler is also responsible for evaluating the workspace and ensuring that the area in which the work is to be undertaken is designed using ergonomic best practices and meets all ergonomic requirements to ensure the protection of its employees.

Personal Protective Equipment

Personal protective equipment should be worn during the entire recycling process.



Wear hand protection



Wear a mask



Wear eye protection



Wear foot protection



Wear protective clothing

LED Safety

Broken LEDs must be handled properly to ensure the safety of your employees and mitigate any hazards. Package broken LEDs in an appropriate container to properly manage the hazards associated with the materials and store only with compatible materials. All waste must be properly classified, packaged, and labeled in accordance with all relevant laws and regulations.

Hazard Warnings



Broken glass hazard



Sharp edges—cut hazard




Chemical exposure hazard



Chemical inhalation hazard


Recommended Tools



Disassembly Instructions

1. Remove the cables.

>> Unplug both ends of the power cable.








Warning: Before continuing disassembly, wait 10 minutes after unplugging the device for stored energy to discharge.

>> Cut off the display cables.





2. Pry in between the cover glass and the enclosure. Pull away the cover glass from the magnetic frame.









3. Remove the LCD cell and the LCD backlight unit.


>> Unscrew the six Torx T10 fasteners holding the LCD cell and the LCD backlight unit to the enclosure.







>> Pry up the LCD backlight unit.










Cut off the cables from the LCD backlight unit to remove the LCD cell and the LCD backlight unit. Set the enclosure aside.







4. Place the LCD cell facedown. Pry off the display logic board and the display logic board cover.












5. Pry off the plastic sheet.








6. Cut off the wires from the back side of the display.








7. Remove the metal frame.

>> Cut the foil and the plastic tape around the display.





Sharp edges—cut hazard







>> Unscrew the six Torx T10 fasteners.






>> Pull the metal frame off the LCD cell.






8. Remove the plastic frame and the LCD cell.

>> Unscrew the five Phillips fasteners holding the plastic frame to the display.








>> Pry the LCD cell off the plastic frame.




Broken glass hazard





Chemical exposure hazard






>> Pull off the plastic frame.






9. Remove the display films from the mid plate by prying up on a corner.




Tools Used


10. Remove the two LED logic boards from the mid plate by unscrewing the 17 Phillips fasteners. Pull out the LED logic boards.









11. From the enclosure, pry off the fan.








12. Remove the power supply logic board by unscrewing the four Torx T10 fasteners.











13. Remove the speaker by unscrewing the four Torx T10 fasteners.












14. Remove the AC power inlet by unscrewing the three Torx T10 fasteners.












15. Remove the main logic board by unscrewing the six Torx T10 fasteners.











16. Remove the stand.


>> Detach the hinge from the stand by removing the eight Torx T10 fasteners.








>> Slide the enclosure away from the stand.







17. Remove the cable cover and the cable from the enclosure by unscrewing the two Torx T10 fasteners.












18. Pry the two plastic sheets off the enclosure.









19. Pry the three brackets off the enclosure. Pry the camera off the larger bracket.
















20. Pry the inner frame off the enclosure.






Enclosure


21. Pry the microphone off the inner frame.








22. Remove the 25 magnets from the inner frame.









23. Remove the two speakers on the ends of the inner frame.










Material Categorization of Output Fractions

All outputs from this process must be managed, handled, and disposed of in accordance with applicable waste laws and regulations, including but not limited to the Waste Framework Directive and its national enactments in Europe.



Downstream Processing

Ferrous





Fasteners (x61)



Display logic board cover



Metal frame



Cable cover







Brackets

Primary Target Material



Downstream Processing

Glass



Cover glass



LCD cell

Primary Target Material



Potential Additional Materials






Logic Boards



Display logic board



LED logic boards



Main logic board



Power supply logic board

Primary Target Material



Potential Additional Materials








Downstream Processing

Mixed Electronics



Power cable



Cables





Fan



AC power inlet



Camera



Microphone

Primary Target Material



Potential Additional Materials







Downstream Processing

Mixed Plastics



Plastic sheets



Plastic frame



Display films

Primary Target Material



Rare Earth Magnets



Speakers



Magnets (x25)

Primary Target Material



Primary Additional Materials





