

May 2023

### **Contents**

- 3 About This Guide
- 4 Identification
- 5 Directive 2012/19/EU Annex VII Components
- 6 Safety Considerations
- 7 Recommended Tools
- 8 Disassembly Instructions
- 12 Material Categorization of Output Fractions

### **About This Guide**

Apple Recycler Guides provide guidance for electronics recyclers on how to disassemble products to maximize recovery of resources. The guides provide step-by-step disassembly instructions and information on the material composition to help recyclers direct fractions to the appropriate material recycler.


To conserve important resources, we work to reduce the materials we use and aim to one day source only recycled or renewable materials in our products. A key path to reaching that goal is resource recovery from end-of-life electronics.

Disassembly procedures are intended to be performed only by trained electronics recycling professionals. The recycler is responsible for independently evaluating and ensuring compliance with all applicable environmental, health, and safety laws related to the work. These include but are not limited to laws relating to the management, handling, shipping, and disposal of the outputs of this work as waste and laws in place to ensure the health and safety of all employees who support this work.

For questions or feedback about this guide, email contactesci@apple.com.

# Identification

You can find the model number of the AirTag on the cosmetic cover under the battery.



Model number: A2187

# Directive 2012/19/EU Annex VII Components

Directive 2012/19/EU Annex VII requirements apply to the following substances and components.

Substance/Component	Apple Part Name	Removal Instructions
Battery	Coin cell battery	Follow steps 1–2
No further substances or components as listed in Annex VII		

### **Safety Considerations**

The recycler is responsible for independently evaluating all activities undertaken by its employees to perform or support the work and ensuring compliance with all applicable health and safety laws related to the work. These include but are not limited to laws relating to the health and safety of all employees who perform or support this work. The recycler is also responsible for evaluating the workspace and ensuring that the area in which the work is to be undertaken is designed using ergonomic best practices and meets all ergonomic requirements to ensure the protection of its employees.

### Personal Protective Equipment

Personal protective equipment should be worn during the entire recycling process.



Wear hand protection



Wear protective clothing



Wear eye protection



Wear foot protection


# **Recommended Tools**


Precision slotted screwdriver




# **Disassembly Instructions**


1. Remove the battery compartment door by pressing it with both thumbs while twisting counterclockwise.







2. Remove the coin cell battery.






## **3.** Pry the cosmetic cover off the enclosure.







## **4.** Pry the speaker off the enclosure.







# **5.** Pry the main logic boad off the enclosure.






# **6.** Pry the coil off the enclosure.





### **Material Categorization of Output Fractions**

All outputs from this process must be managed, handled, and disposed of in accordance with applicable waste laws and regulations, including but not limited to the Waste Framework Directive and its national enactments in Europe.



#### Fraction

### **Downstream Processing**

### **Logic Boards**



Main logic board

### **Primary Target Material**



#### **Potential Additional Materials**







#### **Mixed Electronics**



Coi

### **Primary Target Material**



#### Fraction

#### **Downstream Processing**

#### **Mixed Plastics**



Cosmetic cover



Enclosure

### **Primary Target Material**



#### **Rare Earth Magnets**



Speakei

### **Primary Target Material**



#### **Potential Additional Materials**



